Remington Arms Company, Inc. 870 Remington Drive PO Box 700 Madison, NC 27025-0700 (336) 548-8700 800-243-9700

# REMINGTON

# Arms Company, Inc.

# MODEL 10 PUMP ACTION SHOTGUN

- Shooting Safety Commandments
- Information
- Instructions for Operation & Care of Rifle
- Components Parts Listing
- Value and Reference Book Listing

NOTE: We are pleased to accommodate your request for the Model 10 Pump Action Shotgun information. The following documentation represents all information available on this model from the Remington Arms Co., Inc.

DO NOT MAKE CHANGES OR ALTERATIONS TO ANY PARTS OF A FIREARM. USE ONLY REMINGTON PARTS. NEVER MAKE AN ADJUSTMENT TO THE TRIGGER, OR CHANGE THE SHAPE OR SIZE OF THE SEAR, SEAR NOTCH, OR OTHER PARTS.

## **Ten Commandments of Shooting Safety**

- 1. Always keep the muzzle pointed in a safe direction.
- 2. Firearms should be unloaded when not in use.
- 3. Don't rely on your gun's "safety".
- 4. Be sure of your target and what is beyond it.
- 5. Use correct ammunition.
- 6. If your gun fails to fire when the trigger is pulled, handle with care!
- 7. Always wear eye and ear protection when shooting.
- 8. Be sure the barrel is clear of obstructions before shooting.
- 9. Do not alter or modify your gun, and have guns serviced regularly.
- 10. Learn the mechanical and handling characteristics of the firearm you are using.

# Remington Repeating Shotgun

"Pump Action"

Solid Breech

Hammerless

Take-Down

#### Made in 12 Gauge Only

HE Remington 1908 Model, solid breech, hammerless, take-down, six-shot repeating Shotgun is an example of the highest development of the gunmakers' art. It embodies many new and novel scatures and eliminates those which are objectionable in repeating shotguns of the present day. Beauty of design, persection of workmanship and finish are strikingly apparent. Absence of projecting parts adds symmetry to its altogether pleasing and graceful lines. It handles sast and balances persectly, due in large measure to the grip of stock being more nearly in line with the barrel than any other design of repeating shotgun yet produced. Operation of the mechanism causes no change in the exterior appearance of the gun, excepting in the position of the slide-handle or sore-arm, which is not unsightly.

SOLID BREECH
The design of receiver or frame provides for a SOLID BREECH. There are no openings in top or sides of receiver to weaken it, or allow dirt, snow, rain or

other foreign substance to reach the mechanism, to rust or prevent its working under all conditions. But a feature of much GREATER IMPORTANCE to the shooter and one to which we desire to draw ESPECIAL ATTENTION, is the fact that the receiver is ABSOLUTELY SOLID in the rear. The breech block does not slide out, nor is there an opening of any description

at this point, affording absolute protection no matter what may occur against the breech block, firing-pin, powder gases, defective primers, grease, etc., from blowing back into the eyes or face of the shooter with attendant liability of serious injuries.

The loading and ciceting of shells is done through an opening in the under side of receiver, with the advantage that ejected shells are kept away from the face of the shooter and from interfering with the aim.

ijected shells are kept
from the face of the
r and from interfering
he aim.

The hammerless feature affords protection from liability of accidental

tection from liability of aecidental discharge common to repeating guns of the hammer type and the absence of a projecting hammer adds greatly to the attractive appearance of the gun.

# ngton Repeating Shotgun

" Pump Action"



Cas Me.

TO PLACE GUN rearward until stopped and 11 2 C E

of stop lugs on magazine hold slide handle forward place. Action bar is thus ter turn by means of lever. and turn magazine a quarprotected, as shown in Cui Turn magazine lever into

# Directions for Operating

ayor or KAGAZING Close action by pushing slide handle forward. Turn gun upside down. Place shells on breech block and push well into magazine, which holds five shells.

FROM MAGAZINE handle smartly rearward and forward. TO LOAD BARREL Press the buston on right side of receiver and move slide

TO MAKE "SAPE" WHEN LOCKED Push safety slide (No. 53) rearward and the trigger will be locked.

WHEN COCKED TO OPEN GUN pleied; otherwise the amply shell will be ejected without feeding tha next loaded from the magasine. Be surs to bring back the slide as far as it will go. shell from the magazine. Be sure to bring back the alide as far as it will go. eciver and move slide handle rearward. After firing a shelt be surs the full rearward movement of the slide is com-Press action bar lock button (No. 3) nn right side of re-

SHELLS FROM CHAMBER TO REMOVE LOADED drawn from the barrel by this operation) at the opening in the bottom of she action by pulling slide handle back rather slowly and catch the loaded shell (which will be with-Press button on right side of receiver and open

SHELLS FROM MAGAZINE TO REMOVE LOADED

ceiver and with the fingers remove the shell which lies above the carrier. This operation will move slide handle slightly forward; by moving it rearward the next shell is released from the magazine and may be removed in the same manner Repeat until the magazine is empty. Keep gun right side up when removing zine; then push carrier up against side of rewhich will release the next shell from the maga-Complete the rearward movement of slide handle

# igion Repeating Shotgun

Directions for Scuing Up and Taking Down

of this lever unscrew ningasine (No. 47) a quarter turn. Push slide handle TOGETHER. Pull margaine (No. 47), which will release magazine lever (No. 40). (No. 34) forward until end of magazine is even with barrel yoke (No. 12). Pusty nver magazine lever derent (No. 44) on front end of Pull magazine lever nut until stopped (Cut No. 1). By means as difficulty will be experienced in putting gun to-

BEFORE ATTEMPTING PULL TRIGGER TOGETHER TO PUT GUN gellier if cocked. assembling the gun will not be detrimental to the arm. Breech Block (14) must be forward and held firmly against Top of Receiver (No. 53). If breech Snapping the trigger before

block is not in forward position, jar into place by holding receiver downward, striking front end on palm. Grasp the barrel near breech with left band (Cut

No. 2), holding slide handle far as possible. Hold the and magazine forward as pressing thumb through the sition with the right hand, opening in under side to hold Breech Block forward receiver in an inverted po-

Cal. No.

barrel yoke is firmly against the face of the receiver. Screw a quarter turn celver. Enter barrel with magazine outward, as shown in Cut No. 2, until the and against Top of Reuntil the qualifying lines on under side of barrel yoke and receiver meet (Cut No.3).

Millimit bar (No. 1) engages breach Still holding Breech Block against top of block and starts it rearward. slide handle back until action Receiver with thumb, pull

zine into receiver and screw a quarter turn. By means of magazine lever, push maga-Turn magazine lever into place.

CON DOWN TO TAKE Cus No. 1

tent on front end of magazine, which will release magazine Push over magazine lever de-

lever out until stopped (Cut No. 1). By means of this lever, unscrew maga-structurities of zine a quarter turn. Push slide handle forward until magazine and action bar are

a quarter turn (Cut No. 2), and pull out of receiver magazine near receiver (Cut No. 3), unserew barrel free from receiver (Cut No. 3). Grasp the barrel and

Cat No. 1

1,

# Remington Repeating Shotgun

(Pump Action)


Solid Breech

2

#### Hammerless

Take-Down

Made in 12 Guage Only



Furnished with solid ribbed barrel instead of plain at an advance of \$6.75 list.

A six shot repeater designed especially for trap shooting purposes. This grade differs from No. 3 Trap in that the stock and fore-arm are American Walnut, the stock being furnished in but one dimension which is 14 inches in length, drop 2 inches at heel and 1½ inches at comb. The majority of trap shooters have found these dimensions to be the best adapted for trap shooting purposes. The barrel is of Remington steel and the top surface is neatly matted its entire length which prevents the reflection of light that might interfere with the shooter's sighting. It also aids in taking quick and accurate aim. The barrels of the "Trap Special" are especially selected for trap loads and all guaranteed to shoot over 70% of the load in a 30-inch circle at 40 yards.


# Remington. Repeating Shotgun

(Pump Action)


Solid Breech

Hammerless

Take-Down



Six shot repeater, 26, 25, 30 and 32 inch Remington steel barrel, any desired choke. Stock and fore-arm are of the choicest Imported walnut, handsomely checkered by hand, silver name plate initial in stock. The barrel and receiver are finished with a beautiful deep scroll hand engraving with panel on left side of receiver. All working parts are hand polished. Stock dimensions are same as No. 4 Tournament grade. Made in 12 gauge only.



The No. 4 "Premier" grade Pump gun, like our No. 6 Autoloading shotgan, is a work of art, no affort being spared to produce the finest gun in both workmanship and finish as it is possible for a factory to turn out. The receiver and berrel are finished in a beautiful deep scroll hand engraving which brings out the game panels in relief. Owner's initials engraved on name plate, if so desired. Stock dimentions same as No. 4 Tearnament grade. Made in 12 gauge only.


# ington Repeating Shotgun

(Pump Action)

Solid Breech

#### Hammerless

Take-Down



This Gun furnished with 20-Inch Cylinder Barrel only

The Riot grade pump gun is forced especially to shoot buckshot. It is being used in a number of State prisonal also by express a stehmen. It is a six shot repeater made in 18 gauge only. Stock dimensions again as No. 1 Standard grade.

#### Matted Ribbed Barrel



Solid matted rib, advance of \$6.75 list.

The matted ribbed larged is particularly appreciated by shouters who have used a double gun and therefore are accustomed to a continuous line of sight, it also prevents the reflection of light on the lim of the harrel from interfering with the shouters sight. Trap shouters especially find this lecture being to increase their secures. The harrel and this lecture being to increase their secures. The harrel and this lecture being to increase their secures.

Nore-Seg instructions on ordering extra harrels as given on page 8. 3d 1951 Septention 1955

# nington Repeating Shotgun

(Pump Action)

Solid Breech


Hammerless ::

Take-Down

Made in 12 Gauge Only. "Standard" Grade, Weight, 734 lbs.

Furnished with matted ribbed barrel instead of plain at an advance of \$6.75 list.

Six shot repeater, 28, 28, 30 and 32 inch Remington steel barrel any desired choke. 30 inch full choke sent unless otherwise specified. Half-pistol grip stock and fore-arm of American walnut, regular dimensions 131/2 inches long, drop at heel 21/2 inches, drop at comb 134 inches. Any other length or drop of stock made to order at an advance of \$10.




Furnished with matted ribbed barrel instead of plain at an advance of \$6.75 list.

Same as No. 1 Standard grade with the exception that the stock and fore-arm are of selected Imported walnut, half-pistol grip and fore-arm are neatly checked. Will furnish made to order, without extra charge, lengths from 13% inches to 15 inches, drops 2% inches to 3% inches at the heel. Any other length or drop of stock made to order at an advance of \$10.

Norz.-For extras on Pump gun refer to page 89.

### COMPONENT PARTS

Model 10 Repeating Shotgun



REMINGTON ARMS COMPANY, INC.

Remington Ilion Works Ilion, N. Y., U. S. A.

1:14.

# LIST OF COMPONENT PARTS

# MODEL 10 REPEATING SHOTGUN

No.		•
	Part	No. Part
U-1	Antin- m -	AAPL
Ū-i	Action Bar, Grade A.B.C.	U-37 Foresend Name
Ŭ-1		
LETTER WORKS	Grade 10.E	The state of the s
	Grade 10-F	- Grade 10-1 B C
U-1 U-2 U-8	Action Bar Lock	Guard, Grade 10.10
	Action Bar Lock Button,	U-36 Guard, Grade 10-E
f7 o:		U-38 Guard, Grade 10-F
0-29	Action Bar Lock, complete.	U.74 Guard Serew U.71/2 Gillard Screw Check e
U-5		U.74 Gnard Screw Check Screw
U-69	Action Bar Lock Shoe	
<u>U-6</u>		
V-7	Action Bar Stud	U-108 Latch Spels
	Action Bar Lock Piers	U-108 Latch Spring U-39 Main Spring
		U-40 Magazina I
<u>U</u> -10		
U-83		U-42 Magazia
U-11	Barrel Adj't's Bush's Lock	U-42 Magazine Lever Spring
	Screw Lock	U-44 Magazine Lever Detent
U-43	Barrel I.	U-44/2 Magazine Lever Detent Pin U-46 Magazine Lever Detent Pin
U-45	Screw Barrel Lug Barrel Lug Screw	U-44½ Magazine Lever Detent U-46 Magazine Plug Screw U-47 Magazine Tube
, U-80	Barrel Lug Screw	U-47 Magazine Tube U-50 Magazine Plus
U-12		
U-12	Barrel Yoke, Grade A, B, C	
U-12		
U-12		
<b>U-13</b>	Grade F Barrel Yoke Stands	
U-14	Barrel Joke Stop Screw	' ''''''''''''''''''''''''''''''''''
U-141/2		
U-15	Breech Block, complete	SWICES DIDE RAIL
U-16		U-55 Safety Slide U-551/ Safety Slide
U-20		
U-23		U-56 Safety Slide Pin U-57 Safety Slide S
A CHARLEST U-82	Carrier Stop	
U-25	Carrier Friction Spring	
U-251/2		
U-26		
U-27		- Ocal Spling
U-28		
<b>U</b> -29		
U-ao		
U-31	Extractor Spring	The second of th
U-82		
U-33		OLOGIA GIFRINE IN P
		The state of the s
U-34		
U-84		OWA DOIL WACKET
	- Y'S'SHU. UITEDA ID C	U-63 Tang Screw
	Fore-end, Grade 10-D	U-68 Tang Screw Check Screw
U-84	Fore-end, Grade 10-E	U-64 Trigger
U-84	Fore-end. Grade 10-E	
	Fore-end, Grade 10-F	and the second s
		U-66 Trigger Spring
	3.7 1 2 2	

#### EXPLANATION OF OPERATION

Grasp the fore-end firmly and pull back, which moves action bar into re ceiver. The action bar draws the breech block below the recoil shoulder, is the receiver; at the same time while the block is moving backward, the firing pin, which is in the breech block, is cocked. Near the end of backward stroke the breech block turns the carrier to bottom of receiver, allowing the shell to come from the magazine back upon the carrier. The arm is now in position as shown in "Sectional View," "Action Open."

Pushing the fore-end forward moves the carrier up with the shell until the shell is brought into the barrel and locked there by the breech block. The sea cannot be disengaged from the firing pin, because the trigger cannot reach the sear until the breech block has locked the shell securely in the barrel.

The gun may be made "safe" by pushing the safety toward the rear, when the trigger cannot be pulled. The fore-end cannot be pulled back when the gun is cocked because the action is locked by the action bar lock engaging it slot in side of receiver. This may be released either by firing the arm or by pressing the release button on the right side of receiver, when the action may be opened, if it is not desired to fire the shell.

Assume that the gun has been fired—the arm is then in position as shown in "Sectional View," "Action Closed." Pull back fore-end. The extractor or the front end of the breech block grasps the rim of the shell and pulls it out The shell is held in the top of the receiver by two ribs until drawn fully out or barrel when the extractor, extractor spring and ejector spring, which are in top of the receiver, push the empty shell straight down and out of the button of the receiver.

#### CARE OF FIREARMS

A firearm should be cleaned as quickly as possible after shooting. Delay causes the fouling to become sticky and hard, making removal difficult REMINGTON Powder Solvent is highly recommended for this purpose.

Always clean the barrel from the breech. All REMINGTON firearms are made in Take-Down style so they can be cleaned in this manner. If cleaned from the muzzle the dirt is pushed back into the action and the cleaning rod is apt to bend or break the ejector spring causing failure to operate properly.

Another effective means of cleaning is by the use of boiling water, which should be poured through the barrel.

Care should be taken that the barrel is thoroughly dried, then greased with a heavy grease, preferably REMINGTON Gun Grease.

When the gun is again used the grease should be carefully removed. All mechanism and surfaces should be cleaned and lubricated with a thin oil.

Rem Oil, which has been developed after long and careful experimental work at our arms factory, is highly recommended for this purpose. It is in general use at our plants.

The sear spring located in bottom of breech block should be kept screwed in as far as possible. Do not remove barrel lug screw or attempt to remove barrel lug or barrel yoke, as these have been carefully adjusted by special factory tools.

If stock becomes slightly loose from shrinkage of wood it should be tightened immediately by removing butt plate and turning bolt tightly, using a long screwdriver in deep hole of stock.

#### Firearms Value & Reference Books

NOTE: We do not provide information on firearms' values. You may want to have your firearm appraised by a gunsmith. The following sources may also be helpful. We do not accept responsibility for the goods or services provided by these sources.

### Firearms Value Books

Blue Book of Gun Values
Blue Book Publications
8009 34th Avenue South #175
Minneapolis, MN 55425
800-877-GUNS

Flayderman's Guide to Firearm Values

Gun List

Modern Gun Values

Krause Publications

700 East State Street

Iola, WI 54990-0001

847-573-8530

Gun Trader's Guide Stoeger Publishing Company 5 Mansard Court Wayne, NJ 07470 973-872-9500

#### Reference Books

The Remington 700
John Flacy
Brownells, Inc.
200 South Front Street
Montezuma, IA 50171
515-623-5401

Shooter's Bible
Stoeger Publishing Company
5 Mansard Court
Wayne, NJ 07470
973-872-9500

Cartridges of the World
Frank C. Barnes
Standard Catalog of Firearms
Krause Publications
700 East State Street
Iola, WI 54990-0001
847-573-8530

Remington, America's Oldest
Gunmanker
Remington Arms Co.
PO Box 700
Madison, NC 27025
Attention: History Book
800-423-8495